





































| Original | Sustituto |
|---|---|
|  Power |  Power |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  Radio / AV |  TV/R |
|  Lang / -/-- |  Dual |
|  Vol+ |  Vol + |
|  Vol- |  Vol - |
|  Mute |  Mute |
|  CH+ |  Ch + |

| Original | Sustituto |
|--|---|
|  CH- |  Ch - |
|  Info |  Info |
|  EPG |  Guide |
|  Up |  Up |
|  Left |  Left |
|  Right |  Right |
|  Down |  Down |
|  Exit |  Exit |
|  Yellow / Pause |  Yellow |
|  Blue / >> |  Blue |
|  @ / Stop |  Smart |
|  @ / Stop |  Stop |
|  Rec / [] |  Rec |
| | |
| | |
| | |
| | |





| Original | Sustituto | |
|------------|---|---------------|
| PWR On/Off |  | Power |
| Mute |  | Mute |
| Epg |  +  | Shift + Guide |
| App |  | Media |
| Info |  | Info |
| TV |  | TV/R |
| Text |  | Text |
| Menu |  | Menu |
| Menu Up |  | Up |
| Display |  +  | Shift + Info |
| Menu Left |  | Left |
| OK Enter |  | Ok |
| Menu Right |  | Right |
| Exit |  | Exit |
| Menu Down |  | Down |
| Back |  | Back |
| Volume+ |  | Vol + |

| Original | Sustituto | |
|--------------|---|--------|
| CH/Page+ |  | Ch + |
| Volume- |  | Vol - |
| CH/Page- |  | Ch - |
| 1. ? |  | 1 |
| 2abc |  | 2 |
| 3def |  | 3 |
| 4ghi |  | 4 |
| 5jkl |  | 5 |
| 6mno |  | 6 |
| 7pqrm |  | 7 |
| 8tuv |  | 8 |
| 9wxyz |  | 9 |
| Guide Pilote |  | Guide |
| 0/10 |  | 0 |
| FAV Pref. |  | Pre Ch |
| Red |  | Red |
| Green |  | Green |



