



















































Original	Sustituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 ↔	 Pre Ch
 Back	 Back
 Menu	 Menu
 Netflix	 Media
 Internet	 Smart
 Ok	 Ok

Original	Sustituto
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Vol+	 Vol +
 Vol-	 Vol -
 P+	 Ch +
 P-	 Ch -
 Mute	 Mute
 i	 Info
 Exit	 Exit
 Source	 AV
 Q.Menu	 D. Menu
 EPG	 Guide
 TXT	 Text
 *	 Format
 */Q	 3D





Original	Sustituto	Original	Sustituto
 [>]	 Options		
 Lang	 Dual		
 Subt.	 Subt		
 Shift + Format	 Shift + Format		
 TV	 TV/R		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 Rec	 Rec		
 Play	 Play		
 Stop	 Stop		
 Pause	 Pause		
 <<	 <<		
 >>	 >>		

