











































































































Original		Sustituto		Original		Sustituto	
	Power		Power		Left		Left
	Mute		Mute / Dimmer		Enter		OK
	1		1		Right		Right
	2		2		Menu		Menu / Home
	3		3		Down		Down
	4		4		Exit		Exit / Cancel / Clear
	5		5		Vol +		Vol+
	6		6		List		Smart / List
	7		7		CH +		CH+ / Page+
	8		8		Vol -		Vol-
	9		9		CH -		CH- / Page-
	Source		AV / Input / RDS		Fav		Fav / Marker / PC
	0		0		Sleep		Sleep / Timer
	Info		Info / Angle		Index		D.Menu / Top
	DMP		Display / Media		Recall		Back / Return
	Up		Up		Red / <<		Red / Netflix / Search
	EPG		Guide / EPG / -/-		Red / <<		<< / Tune-





Original		Sustituto		Original		Sustituto	
	Green / >>		>> / Tune+		Rec		Rec / Rec Mode
	Green / >>		Green / APP / Repeat				
	Yellow / I<<		I<< / Preset-				
	Yellow / I<<		Yellow / YouTube / Repeat				
	Blue / >>I		>>I / Preset+				
	Blue / >>I		Blue / Prime Video / Random				
	Text / Play/Pause		Text / Goto				
	Text / Play/Pause		Play / Slow				
	Text / Play/Pause		Pause / Step / Freeze				
	Stop / Still		Stop / Hold				
	Timer / Subtitle		Subtitle / EQ				
	Timer / Subtitle		Shift + Sleep / Timer				
	Size / Aspect		Picture / Format				
	Size / Aspect		Zoom / Size				
	Cancel [≡X]		Shift + Exit / Cancel / Clear				
	Radio		TV/Radio /				
	Audio / I/II		Audio / Lang I/II				

