







































































Original	Sustituto	Original	Sustituto
 Power	 Power	 i	 DISPLAY INFO Info
 1	 1	 P+	 + CH Ch +
 2	 2	 P-	 - CH Ch -
 3	 3	 P+	
 4	 4	 P-	
 5	 5	 P+	
 6	 6	 P-	
 7	 7	 OK	
 8	 8	 P+	 + VOL Vol +
 9	 9	 P-	 - VOL Vol -
 0 AV	 0		 SOUND DUAL Dual
 P/C CL	 FAV PRE-CH Pre Ch		 D Blue
			 C Yellow
 <<	 <<		 B Green
 ▶	 ▶		 A Red
 >>	 >>		 >>I
 TXT	 REPEAT TEXT Text		 I<<


































































Original	Sustituto	Original	Sustituto
	Power		Power
	Pause		Pause
	<<		<<
	Play		Play
	>>		>>
	i		Info
	Rec		Rec
	Stop		Stop
	P+		Ch +
	P-		Ch -
	Up		Up
	Down		Down
	☺+		Smart
	☹-		Media





Original		Sustituto		Original		Sustituto	
	Power		Power		i		Info
	1		1		Up		Up
	2		2		Down		Down
	3		3		Right		Right
	4		4		Left		Left
	5		5		OK		Ok
	6		6		P+		Ch +
	7		7		P-		Ch -
	8		8		Vol+		Vol +
	9		9		Vol-		Vol -
	0/AV		0		Audio		Dual
	P/C/CL		Pre Ch		Blue		Blue
	Pause		Pause		Yellow		Yellow
	<<		<<		Green		Green
	Play		Play		Red/OTR		Red
	>>		>>		Next		>>I
	TXT		Text		Prev		I<<



