






























































Original	Sustituto	Original	Sustituto
	Power		Power
	Mute		Mute / Dimmer
	Colour-		<< / Tune-
	Colour+		>> / Tune+
	Brightness/DX-		I<< / Preset-
	Brightness/DX+		>>I / Preset+
	Blue/Audio		Audio / Lang I/II
	Red/Picture		Picture / Format
	Green/Timer		Sleep / Timer
	TXT		Text / Goto
	0/AV		AV / Input / RDS
	Up		Up
	i		Info / Angle
	Left		Left
	OK		OK
	Right		Right
	Down		Down
	Vol+		Vol+
	Peri		Smart / List
	P+		CH+ / Page+
	Vol-		Vol-
	P-		CH- / Page-
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0/AV		0
	Red/Picture		Red / Netflix / Search
	Green/Timer		Green / APP / Repeat























Original	Sustituto	Original	Sustituto
 Yellow/Format	 Yellow / YouTube / Repeat		
 Blue/Audio	 Blue / Prime Video / Random		
 Yellow/Format	 Shift + Picture / Format		
 A/B	 Shift + Yellow / YouTube /		








Original	Sustituto	Original	Sustituto
	Power		Power
	Mute		Mute / Dimmer
	Brightness/DX-		I<< / Preset-
	Brightness/DX+		>>I / Preset+
	Blue/Audio		Audio / Lang I/II
	Red/Picture		Picture / Format
	Green/Timer		Sleep / Timer
	TXT		Text / Goto
	Up		Up
	i		Info / Angle
	Left		Left
	OK		OK
	Right		Right
	Down		Down
	Vol+		Vol+
	Peri		Smart / List
	P+		CH+ / Page+
	Vol-		Vol-
	P-		CH- / Page-
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0/AV		0
	Red/Picture		Red / Netflix / Search
	Green/Timer		Green / APP / Repeat
	Yellow/Format		Yellow / YouTube / Repeat
	Blue/Audio		Blue / Prime Video / Random
	Yellow/Format		Shift + Picture / Format


































































Original	Sustituto
 A/B	 +  Shift + Yellow / YouTube / REPEAT A-B

Original	Sustituto






Original	Sustituto	Original	Sustituto
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0/AV		0
	Up		Up
	P+		CH+ / Page+
	Right		Right
	Vol+		Vol+
	Left		Left
	Vol-		Vol-
	OK		OK
	Down		Down
	P-		CH- / Page-
	i		Info / Angle
	TXT		Text / Goto
	A/B		Yellow / YouTube / Repeat
	Red/Picture		Red / Netflix / Search
	Red/Picture		Picture / Format
	Green/Timer		Green / APP / Repeat
	Green/Timer		Sleep / Timer
	Blue/Audio		Blue / Prime Video / Random
	Blue/Audio		Audio / Lang I/II
	Brightness/DX-		I<< / Preset-
	Brightness/DX+		>>I / Preset+
	Mute		Mute / Dimmer





Original	Sustituto	Original	Sustituto
 Power	 Power		
 P+	 CH+ / Page+		
 Play	 Play / Slow		
 Stop	 Stop / Hold		
 P-	 CH- / Page-		
 Rec	 Rec / Rec Mode		
 TXT / Exit	 Text / Goto		
 TXT / Exit	 Exit / Cancel / Clear		
 A/B	 Yellow / YouTube / Repeat		
 Pause	 Pause / Step / Freeze		
 <<	 << / Tune-		
 >>	 >> / Tune+		

