























































































Original	Sustituto	Original	Sustituto
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0 / AV		AV / Input / RDS
	0 / AV		0
	Up / P+		CH+ / Page+
	Up / P+		Up
	OK		OK
	Right / Vol+		Right
	Right / Vol+		Vol+
	Left / Vol-		Vol-
	Left / Vol-		Left
	Down / P-		Down
	Down / P-		CH- / Page-
	i		Info / Angle
	AKT / TV-Guide		Guide / EPG / -/-
	Mute		Mute / Dimmer
	TXT		Text / Goto
	Red / Picture		Picture / Format
	Red / Picture		Red / Netflix / Search
	Green / Timer		Sleep / Timer
	Green / Timer		Green / APP / Repeat
	Yellow / Pause		Yellow / YouTube / Repeat
	Yellow / Pause		Pause / Step / Freeze
	Blue / Audio		Blue / Prime Video / Random
	Blue / Audio		Audio / Lang I/II
	Color-		I<< / Preset-





Original	Sustituto	Original	Sustituto
 Color+	 >>I / Preset+		
 Brightness-	 << / Tune-		
 Brightness+	 >> / Tune+		
 PIP	 D.Menu / Top		
 ?	 Menu / Home		
 Size	 Zoom / Size		
 AUX	 Shift + 7		
 AUX	 Smart / List		

