


































































































Original	Sustituto
 Power	 Power
 TV	 TV/R
 Q.Menu	 Menu
 Picture	 Format
 Sound	 Shift + Dual
 Input	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 List	 List

Original	Sustituto
 Q.View	 D. Menu
 FAV	 Pre Ch
 I/II	 Dual
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Page+	 Ch +
 Page-	 Ch -
 Time	 Shift + AV
 Reveal	 Media
 Update	 Subt
 Settings	 Options
 Hold	 Smart
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left





Original		Sustituto		Original	Sustituto
	OK		Ok		
	Back		Back		
	Exit		Exit		
	Text		Text		
	Stop		Stop		
	<<		<<		
	Index		Info		
	Play		Play		
	Pause		Pause		
	>>		>>		
	Red		Red		
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		

