













































Original	Sustituto	Original	Sustituto
On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Update	 Smart	Menu Off	 Exit
Reveal	 Media	Menu Down	 Down
Txt Stop	 Stop	Back	 Back
Info	 Info	Volume+	 Vol +
Subt.List	 Subt	Chan.Up	 Ch +
Sleep Timer	 Sleep	Volume-	 Vol -
Return TV	 TV/R	Menu audio	 Dual
Menu video	 D. Menu	Chan.Down	 Ch -
Text	 Text	1	 1
Txt Expand	 Eject	2	 2
TV/AV	 AV	3	 3
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Display	 Shift + Info	6	 6
Menu Left	 Left	7	 7



Original	Sustituto	Original	Sustituto
8		8	
9		9	
Guide -/-- 1.		Guide	
0/10		0	
2.Fav P/C 2.		Pre Ch	
Red		Red	
Green		Green	
Yellow		Yellow	
Blue		Blue	
Color+ P.Std		Format	
Bright- Sys		Options	
AV 2	 + 	Shift + AV	
Color- S.Std	 + 	Shift + Dual	
Contrast+	 + 	Shift + Ch +	
Contrast-	 + 	Shift + Ch -	
On Pip	 + 	Shift + 1	
Swap	 + 	Shift + 2	
Rotate Pip	 + 	Shift + 3	
Still	 + 	Shift + 4	
Dim Pip	 + 	Shift + 5	
Help	 + 	Shift + 6	

