





























Original	Sustituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 List	 List
 OPT	 Options
 Back	 Back
 Exit	 Exit
 EPG	 Guide
 Info	 Info

Original	Sustituto
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 CH+	 Ch +
 CH-	 Ch -
 Menu	 Menu
 TXT	 Text
 TV/♪	 TV/R





Original	Sustituto	Original	Sustituto		
	*		Pre Ch		
	APP		Media		
	Disp		+		Shift + Info

