



Original	Sustituto
Power	Power
Sleep	Sleep
Mute	Mute
Timer	AV
EPI	Guide
SUBTL	Subt
Audio	Shift + Dual
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0

Original	Sustituto
16:9	Format
Lang	Dual
RCL	Back
FAV	Pre Ch
Page+ / Timeshift	Shift + Ch +
Page- / V-Format	Shift + Ch -
Page- / V-Format	Shift + Format
Up / CH+	Up
Up / CH+	Ch +
Down / CH-	Down
Down / CH-	Ch -
Right / Vol+	Right
Right / Vol+	Vol +
Left / Vol-	Left
Left / Vol-	Vol -
OK	Ok
Menu	Menu





Original	Sustituto
Info	Info
TXT	Text
Exit	Exit
Red / SAT	Red
Green / Zoom	Green
Green / Zoom	Eject
Yellow / Pause	Yellow
Yellow / Pause	Shift + Pause
Blue / TV/Radio	Blue
Blue / TV/Radio	TV/R
<<<	<<<
>>>	>>>
Play / Pause	Play
Play / Pause	Pause
Stop	Stop
I<<<	I<<<
>>>I	>>>I

Original	Sustituto
Slow	Shift + Play
Rec	Rec
Media	Media
Game	Smart
PVR	Shift + Smart
HDD	Shift + Media

