



Original	Sustituto
	Power
	Last
	Mute
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	TV/R
	Audio
	Info
	Mode

Original	Sustituto
	Favor
	Menu
	Sub-T
	Exit
	Up
	Down
	Right
	Left
	Ok
	Ch +
	Ch -
	Vol +
	Vol -
	Red
	Green
	Yellow
	Blue





Original	Sustituto	Original	Sustituto
Power		Power	
Last		Pre Ch	
Mute		Mute	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
0		0	
TV/R		TV/R	
Audio		Dual	
Info		Info	
Mode		D. Menu	

Original	Sustituto	Original	Sustituto
Favor		Options	
Menu		Menu	
Sub-T		Subt	
Exit		Exit	
Up		Up	
Down		Down	
Right		Right	
Left		Left	
OK		Ok	
CH+		Ch +	
CH-		Ch -	
Vol+		Vol +	
Vol-		Vol -	
Red		Red	
Green		Green	
Yellow		Yellow	
Blue		Blue	





Original	Sustituto	
Power		Power
Last		Pre Ch
Mute		Mute
1		1
2		2
3		3
4		4
5		5
6		6
7		7
8		8
9		9
0		0
TV/R		TV/R
Audio		Dual
Info		Info
Mode		D. Menu

Original	Sustituto	
Favor		Options
Menu		Menu
Sub-T		Subt
Exit		Exit
Up		Up
Down		Down
Right		Right
Left		Left
OK		Ok
CH+		Ch +
CH-		Ch -
Vol+		Vol +
Vol-		Vol -
Red		Red
Green		Green
Yellow		Yellow
Blue		Blue



