







































































Original	Sustituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 (i)	 Info
 AV	 AV
 Red	 Red
 Green	 Green
 Yellow	 Yellow

Original	Sustituto
 Blue	 Blue
 TV	 TV/R
 Menu	 Menu
 [≡]/Top Menu	 Text
 Back	 Back
 P+	 Ch +
 P-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 ↑/[+]	 Pre Ch
 F.T/L	 Options
 [?]	 3D





Original	Sustituto	Original	Sustituto
	Format		
	Guide		
	D. Menu		
	Exit		
	Media		
	Eject		
	Smart		
	Dual		
	Subt		













	Original	Sustituto	Original	Sustituto
		Power		Power
		(i)		Info
		Menu		Menu
		Up		Up
		Down		Down
		Right		Right
		Left		Left
		OK		Ok
		Top Menu	+	Shift + Menu
		Back		Back
		↑/[+]		Pre Ch
		↓/[]		Guide
		<<		<<
		Play		Play
		>>		>>
		Stop		Stop
		Pause		Pause









Original	Sustituto
 Power	 Power
 (i)	 Info
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Menu	 Menu
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Top Menu	 Shift + Menu
 Back	 Back
 ↓/[]	 Guide
 ↑/[+]	 Pre Ch
 <<	 <<
 Play	 Play

Original	Sustituto
 >>	 >>
 Rec	 Rec
 Stop	 Stop
 Pause	 Pause





Original	Sustituto
 Power	 Power
 Mute	 Mute
 (i)	 Info
 Menu	 Menu
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Top Menu	 +  Shift + Menu
 Back	 Back
 ↑/[+]	 Pre Ch
 ↓/[]	 Guide
 <<	 <<
 Play	 Play
 >>	 >>
 Pause	 Pause

Original	Sustituto
 Stop	 Stop
 (↔)	 Media

