





























































| Original | Sustituto | Original | Sustituto |
|----------------------|-----------|----------------------|----------------|
| Power | Power | Group/Title Skip >>I | Ch + |
| Sleep/A.Stby | Sleep | Stop/PTY | Stop |
| Clock/Timer | AV | Repeat | Text |
| Scan Mode | Green | Top Menu/PG | Shift + Menu |
| Display | Info | Menu/PL | Menu |
| Picture/Adjust | Format | Tuner/Play | 3D |
| Dimmer | Smart | Vol+ | Vol + |
| Play/Pause | Play | Vol- | Vol - |
| Play/Pause USB | Pause | Fade Muting | Mute |
| Play/Pause SD | Media | Return | Shift + Pre Ch |
| Tuner | TV/R | Return | Back |
| Audio In | Dual | On Screen | Shift + Info |
| <</Slow- | << | Set Up | Options |
| >>/Slow+ | >> | Up | Up |
| I<< | I<< | Down | Down |
| I<< Group/Title Skip | Ch - | Right | Right |
| >>I | >>I | Enter/Set | Ok |





| Original | Sustituto | Original | Sustituto |
|--|---|---|---|
|  Left |  Left |  9 |  9 |
|  Audio/MPX |  Red |  0 |  0 |
|  Subtitle |  Subt |  10 |  Guide |
|  Zoom |  Eject |  +10 |  Pre Ch |
|  Sound Mode |  List |  5 |  Shift + 5 |
|  Surround |  Shift + Dual |  6 |  Shift + 6 |
|  C.Voice |  Yellow |  7 |  Shift + 7 |
|  S.Turbo II |  Blue |  8 |  Shift + 8 |
|  HBS |  Shift + Smart |  9 |  Shift + Text |
|  1 |  1 |  10 |  D. Menu |
|  2 |  2 |  0 |  Exit |
|  3 |  3 |  ≥10 |  Shift + Media |
|  4 |  4 | | |
|  5 |  5 | | |
|  6 |  6 | | |
|  7 |  7 | | |
|  8 |  8 | | |

