



Original	Sustituto
	Mute / Dimmer
	Power
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Info / Angle
	0
	AV / Input / RDS
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat

Original	Sustituto
	Blue / Prime Video / Random
	TV/Radio /
	Up
	Menu / Home
	Left
	OK
	Right
	Text / Goto
	Down
	Back / Return
	CH+ / Page+
	Vol+
	CH- / Page-
	Vol-
	Shift + Stop /
	<< / Tune-
	Play / Slow



