















Original	Sustituto
	Power
	Mute
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	<< / Tune-
	>> / Tune+
	I<< / Preset-
	>>I / Preset+
	Play / Slow
	Pause / Step / Freeze
	Stop / Hold
	[≡i] Display / Media
	Text
	Subtitle
	Freeze

Original	Sustituto
	Info
	Menu
	Source
	EPG
	Exit
	Up
	Down
	Right
	Left
	OK
	Vol+
	Vol-
	FAV
	Rec
	CH+
	CH-
	1



