





































Original	Sustituto
 Power	 Power
 Energy/Saving	 3D
 AV Mode	 Media
 Input	 AV
 Tv/Radio	 TV/R
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 List	 List
 Q.View	 Sleep

Original	Sustituto
 FAV/Mark	 Pre Ch
 Ratio	 Format
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 PR+	 Ch +
 PR-	 Ch -
 Menu	 Menu
 Guide	 Guide
 Q.Menu	 D. Menu
 Back	 Back
 Info	 Info
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left



