



Original	Sustituto
Power	Power
Open/Close	Eject
Tv/DVD	TV/R
PIP	3D
*	Guide
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
AV	AV
[...] /Subtitle	Subt

Original	Sustituto
O)) /Audio	Dual
Rec	Rec
Camera/Angle	Options
Play	Play
Stop	Stop
Pause/Step	Pause
<< Scan	<<
Scan >>	>>
I<< Skip	I<<
Skip >>I	>>I
Menu/List	Menu
Up/PR+	Up
Setup	D. Menu
Down/PR-	Down
Right	Right
Left	Left
OK	Ok





Original	Sustituto
DISPLAY	Info
RETURN	Back
CLEAR	Exit
ZOOM	Shift + Eject
INSTANT SKIP	Media
TITLE	Shift + Guide
REPEAT	Text
PROGRAM	Sleep
RANDOM	Green
A - B	Shift + Play
3D SURR.	Shift + 3D
SEARCH	Shift + TV/R
MARKER	Shift + Subt
THUMBNAIL	Format
CHP ADD	Pre Ch
POWER	Shift + Power
AV	Shift + AV

Original	Sustituto
PR+	Ch +
PR-	Ch -
VOL+	Vol +
VOL-	Vol -
MUTE	Mute
REC MODE	Shift + Rec
TIMER REC	Blue

