












































Original	Sustituto
	
Power	Power
	
Back	Back
	
Home	Smart
	
TV	TV/R
	
Micro	Dual
	
Up	Up
	
Down	Down
	
Left	Left
	
Right	Right
	
Red	Red
	
Green	Green
	
Yellow	Yellow
	
Blue	Blue
	
Vol+	Vol +
	
Vol-	Vol -
	
P+	Ch +
	
P-	Ch -

Original	Sustituto
	
3D	3D
	
123/Input	Media
	
Mute	Mute
	
Mouse Up	>>
	
Mouse Down	<<
	
OK	Ok

