















































Original	Sustituto	Original	Sustituto
	Power		Power
	Home		Smart
	Back		Back
	Micro		Dual
	Tv		TV/R
	Mouse Down		>>
	Mouse Up		<<
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Vol+		Vol +
	Vol-		Vol -
	123/Input		AV
	3D		3D
	Mute/AD		Mute
	P+		Ch +
	P-		Ch -





















Original	Sustituto
 Power	 Power
 Wheel Down	 +  Shift + Down
 OK	 Ok
 Up	 Up
 Down	 Down
 Wheel Up	 +  Shift + Up
 Right	 Right
 Left	 Left
 Back	 Back
 Home / Smart	 Smart
 3D	 3D
 123 / Q.Menu	 +  Shift + Ok
 Vol +	 Vol +
 Vol -	 Vol -
 Mute	 Mute
 P +	 Ch +
 P -	 Ch -

Original	Sustituto
 Ratio	 Format
 List	 List
 Q.Menu	 +  Shift + Menu
 Subtitle	 Subt
 Settings	 +  Shift + Options
 AD / PIP	 Dual
 >>	 >>
 >>	 >>I
 Play	 Play
 <<	 <<
 <<	 I<<
 Rec	 Rec
 Pause	 Pause
 Stop / Live TV	 Stop
 AV Mode	 +  Shift + AV
 Text	 Text
 FAV	 +  Shift + Pre Ch





Original	Sustituto	Sustituto
Exit		Exit
TV / PC	 + 	Shift + Smart
Input		AV
TV / Radio		TV/R
		Blue
		Yellow
		Green
		Red
0		0
AD	 + 	Shift + Subt
Search	 + 	Shift + TV/R
Live Menu		Menu
Recent		Pre Ch
Live Zoom		Eject
App	 + 	Shift + Media
Guide		Guide
Info		Info

Original	Sustituto	Sustituto
T.Opt		Options
Q.View		D. Menu
Energy Saving	 + 	Shift + 3D
9		9
8		8
7		7
6		6
5		5
4		4
3		3
2		2
1		1
My APPS		Media

