



Original	Sustituto
RATIO	Picture / Format
POWER	Power
INPUT	AV / Input / RDS
AV MODE	Info / Angle
ENERGY	Sleep / Timer
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
LIST	Smart / List
0	0
Q.VIEW	Display / Media

Original	Sustituto
VOL+	Vol+
MUTE	Mute / Dimmer
PR+/PAGE UP	CH+ / Page+
VOL-	Vol-
PR-/PAGE	CH- / Page-
UP	Up
LEFT	Left
OK	OK
RIGHT	Right
MENU	Menu / Home
DOWN	Down
RETURN	Back / Return
RED	Red / Netflix / Search
GREEN	Green / APP / Repeat
STOP	Stop / Hold
YELLOW	Yellow / YouTube / Repeat
PLAY	Play / Slow



