







































	Original	Sustituto		Original	Sustituto
	Power		Power		Eco
	RGB		TV/Radio /		Smart / List
	Video		4		
	Still		Pause / Step / Freeze		
	Sleep		Sleep / Timer		
	Blank		Back / Return		
	Menu		Menu / Home		
	Up		Up		
	Ratio		Picture / Format		
	Left		Left		
	OK		OK		
	Right		Right		
	Auto		Display / Media		
	Down		Down		
	Zoom		Zoom / Size		
	Info		Info / Angle		
	Keystone		AV / Input / RDS		

