



| Original | Sustituto | | |
|----------|--------------|--|------------------|
| | Power | | Power |
| | Optical | | Smart / List |
| | Vol+ | | Vol+ |
| | Vol- | | Vol- |
| | Mute | | Mute / Dimmer |
| | EQ. | | Setup / OPT / |
| | Woofer Level | | CH+ / Page+ |
| | Woofer Level | | CH- / Page- |
| | Bluetooth | | 9 |
| | LG TV | | TV/Radio / |
| | PORT.IN | | Picture / Format |
| | Sound Effect | | Sound / Title |
| | *) | | Down |
| | Left | | Left |
| | Right | | Right |
| | AV Sync | | OK |
| | DRC | | Menu / Home |

| Original | Sustituto | | |
|----------|-------------|--|-----------------------|
| | Info | | Info / Angle |
| | Sleep | | Sleep / Timer |
| | Auto Volume | | Audio / Lang I/II |
| | Auto Power | | Exit / Cancel / Clear |

