

















Original	Sustituto
 Power	 Power
 Sound Mode	 Sound / Title
 Dimmer/Sleep	 Smart / List
 Mute	 Mute / Dimmer
 HDMI 1	 Setup / OPT /
 Portable	 Subtitle / EQ
 Vol+	 Vol+
 HDMI 2	 Menu / Home
 Optical	 Zoom / Size
 Vol-	 Vol-
 Coaxial	 Sleep / Timer
 USB Random	 Up
 Tv Speaker/On/Off	 Shift + Smart / List
 I<<<	 I<<< / Preset-
 I<<<	 <<< / Tune-
 Stop	 Stop / Hold
 Stop	 OK

Original	Sustituto
	 >>I / Preset+
	 >> / Tune+
	 Display / Media
	 Play / Slow
	 Down
	 Pause / Step / Freeze
	 Green / APP / Repeat

