
























































Original	Sustituto
 Goto	 Text / Goto
 Open / Close	 Eject / Surround
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 +10	 Guide / EPG / -/--
 Step	 Shift + Pause / Step /
 Slow	 Shift + Play /
 Zoom	 Zoom / Size
 Angle	 Info / Angle

Original	Sustituto
 Prog	 TV/Radio /
 Shuffle	 Blue / Prime Video / Random
 N/P	 D.Menu / Top
 Repeat	 Green / APP / Repeat
 Repeat A-B	 Yellow / YouTube / Repeat
 Title	 Sound / Title
 Subtitle	 Subtitle / EQ
 Setup	 Setup / OPT /
 Up	 Up
 Display	 Display / Media
 Left	 Left
 Enter	 OK
 Right	 Right
 Menu	 Menu / Home
 Down	 Down
 Return	 Back / Return
 Vol+	 Vol+





	Original	Sustituto
	Mute	 Mute / Dimmer
	<<	 << / Tune-
	>>	 >> / Tune+
	Stop	 Stop / Hold
	Vol-	 Vol-
	Audio	 Audio / Lang I/II
	I<<	 I<< / Preset-
	>>I	 >>I / Preset+
	Play / Pause	 Play / Slow
	Play / Pause	 Pause / Step / Freeze

Original	Sustituto

