







































| Original | Sustituto | Original | Sustituto |
|---|------------|---|------------|
|  | Power |  | Power |
|  | Mute |  | Mute |
|  | Home |  | Smart |
|  | Vol+ |  | Vol + |
|  | Vol- |  | Vol - |
|  | Up |  | Up |
|  | Left |  | Left |
|  | OK |  | Ok |
|  | Right |  | Right |
|  | Down |  | Down |
|  | i |  | Info |
|  | :≡ |  | Guide |
|  | Settings |  | Options |
|  | Settings |  | Menu |
|  | Stop |  | Stop |
|  | Rec |  | Rec |
|  | Play/Pause |  | Play |
| | |  | Play/Pause |
| | |  | Pause |

