


































Original	Sustituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right

Original	Sustituto
 Left	 Left
 OK	 Ok
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Red	 Red
 Yellow	 Yellow
 Blue	 Blue
 Green	 Green
 EPG	 Guide
 Subtitle	 Subt
 TTX	 Text
 Audio	 Dual
 i	 Info
 FAV	 Pre Ch
 Tv/Radio	 TV/R





Original	Sustituto	Original	Sustituto
 Video	 Smart		
 Scan	 Media		
 Device	 Options		
 File	 List		
 Zoom	 Eject		
 Roll	 AV		
 Record	 Rec		
 Prev.	 I<<		
 Next	 >>I		
 Play	 Play		
 Pause	 Pause		
 <<	 <<		
 >>	 >>		

Original	Sustituto

