





































Original	Sustituto
 Power	 Power
 Sub-T	 Subtitle / EQ
 Lang	 Audio / Lang I/II
 Mute	 Mute / Dimmer
 EPG	 Guide / EPG / -/--
 Goto	 Shift + Text /
 Page+	 CH+ / Page+
 TTX	 Text / Goto
 Repeat	 Shift + Green / APP /
 Page-	 CH- / Page-
 Menu	 Menu / Home
 Up/CH+	 Up
 Exit	 Exit / Cancel / Clear
 Vol-	 Vol-
 Left	 Left
 OK	 OK
 Right	 Right

Original	Sustituto
 Vol+	 Vol+
 FAV	 Fav / Marker / PC
 Down/CH-	 Down
 Tv/Radio	 TV/Radio /
 1	 1
 2	 2
 3	 3
 Recall	 Back / Return
 4	 4
 5	 5
 6	 6
 Info	 Info / Angle
 7	 7
 8	 8
 9	 9
 0	 0
 <<	 << / Tune-





Original	Sustituto	Original	Sustituto
	>>		>> / Tune+
	I<<		I<< / Preset-
	>>I		>>I / Preset+
	Play		Play / Slow
	Pause/Time Shift		Pause / Step / Freeze
	Stop		Stop / Hold
	Rec		Rec / Rec Mode
	Red/PVR		Red / Netflix / Search
	Green/V-Format		Green / APP / Repeat
	Yellow/Aspect		Yellow / YouTube / Repeat
	Blue/Timer		Blue / Prime Video / Random





Original	Sustituto
Power	Power
Sub-T	Subtitle / EQ
Lang	Audio / Lang I/II
Mute	Mute / Dimmer
EPG	Guide / EPG / -/--
Goto	Shift + Text /
Page+	CH+ / Page+
TTX	Text / Goto
Repeat	Shift + Green / APP /
Page-	CH- / Page-
Menu	Menu / Home
Up/CH+	Up
Exit	Exit / Cancel / Clear
Left	Left
Vol-	Vol-
OK	OK
Right	Right

Original	Sustituto
Vol+	Vol+
FAV	Fav / Marker / PC
Down/CH-	Down
Tv/Radio	TV/Radio /
1	1
2	2
3	3
Recall	Back / Return
4	4
5	5
6	6
Info	Info / Angle
7	7
8	8
9	9
0	0
<<	<< / Tune-





Original		Sustituto		Original		Sustituto	
	>>		>> / Tune+				
	I<<		I<< / Preset-				
	>>I		>>I / Preset+				
	Play		Play / Slow				
	Pause/TimeShift		Pause / Step / Freeze				
	Stop		Stop / Hold				
	Rec		Rec / Rec Mode				
	Red/PVR		Red / Netflix / Search				
	Green/V-Format		Green / APP / Repeat				
	Yellow/Aspect		Yellow / YouTube / Repeat				
	Blue/Timer		Blue / Prime Video / Random				

