





































Original	Sustituto
 Power	 Power
 Red	 Red / Netflix / Search
 Green / I-II	 Sound / Title
 Green / I-II	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 [i+]	 Info / Angle
 [↕]	 Display / Media
 [□]	 AV / Input / RDS
 [?]	 Smart / List
 Smart Audio	 Audio / Lang I/II
 Radio	 TV/Radio /
 Smart Picture	 Picture / Format
 Menu	 Menu / Home
 Up	 Up
 [≡]	 Text / Goto
 Left	 Left

Original	Sustituto
 Right	 Right
 Down	 Down
 Vol+	 Vol+
 Mute	 Mute / Dimmer
 P+	 CH+ / Page+
 Vol-	 Vol-
 P-	 CH- / Page-
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Sleep	 Sleep / Timer



