















































Original	Sustituto
 Sleep	 Sleep / Timer
 Power	 Power
 CBL/SAT	 0
 DVD	 2
 Blu-ray	 5
 GAME	 Fav / Marker / PC
 AUX	 7
 MEDIA PLAYER	 Display / Media
 TV AUDIO	 1
 8K	 4
 TUNER	 6
 USB	 8
 CD	 3
 Bluetooth	 9
 Heos	 Smart / List
 PHONO	 AV / Input / RDS
 INTERNET	 Guide / EPG / -/-

Original	Sustituto
 CH/Page+	 CH+ / Page+
 ECO	 Menu / Home
 Volume+	 Vol+
 CH/Page-	 CH- / Page-
 Mute	 Mute / Dimmer
 Volume-	 Vol-
 Info	 Info / Angle
 Option	 Shift + Setup / OPT / Tools
 Up	 Up
 Left	 Left
 Enter	 OK
 Right	 Right
 Back	 Back / Return
 Down	 Down
 Setup	 Setup / OPT /
 I<< / Tune-	 << / Tune-
 I<< / Tune-	 I<< / Preset-



RADIO




Original	Sustituto
 Sleep	 Sleep / Timer
 Power	 Power
 CBL/SAT	 0
 DVD	 2
 Blu-ray	 5
 GAME	 Fav / Marker / PC
 AUX	 7
 MEDIA PLAYER	 Display / Media
 TV AUDIO	 1
 8K	 4
 TUNER	 6
 USB	 8
 CD	 3
 Bluetooth	 9
 Heos	 Smart / List
 PHONO	 AV / Input / RDS
 INTERNET	 Guide / EPG / -/--

Original	Sustituto
 CH/Page+	 CH+ / Page+
 Volume+	 Vol+
 CH/Page-	 CH- / Page-
 Mute	 Mute / Dimmer
 Volume-	 Vol-
 Up	 Up
 Left	 Left
 Enter	 OK
 Right	 Right
 Back	 Back / Return
 Down	 Down
 I<< / Tune-	 I<< / Preset-
 I<< / Tune-	 << / Tune-
 Play / Pause	 Play / Slow
 Play / Pause	 Pause / Step / Freeze
 >>I / Tune+	 >> / Tune+
 >>I / Tune+	 >>I / Preset+



RADIO



	Original	Sustituto	Original	Sustituto
	Smart Select 1	 Red / Netflix / Search		
	Smart Select 2	 Green / APP / Repeat		
	Smart Select 3	 Yellow / YouTube / Repeat		
	Smart Select 4	 Blue / Prime Video / Random		

