



































| Original | Sustituto |
|--|--|
|  Power |  Power |
|  Mute |  Mute |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  TV/Radio |  TV/R |
|  ←PR |  Back |
|  FAV |  Pre Ch |
|  Menu |  Menu |
|  SAT |  Smart |

| Original | Sustituto |
|---|---|
|  Info |  Info |
|  Page Up |  >>I |
|  Page Down |  I<< |
|  Up / PR+ |  Up |
|  Up / PR+ |  Ch + |
|  Down / PR- |  Down |
|  Down / PR- |  Ch - |
|  Right / Vol+ / W |  Right |
|  Left / Vol- / E |  Left |
|  Right / Vol+ / W |  Vol + |
|  Left / Vol- / E |  Vol - |
|  OK / List |  Ok |
|  OK / List |  List |
|  Exit |  Exit |
|  EPG |  Guide |
|  TV/AV |  AV |
|  Pause |  Shift + Pause |





| Original | Sustituto | Original | Sustituto |
|-------------------|-----------|----------|-----------|
| PAL/NTSC | Format | | |
| UHF | Media | | |
| Red / Audio | Red | | |
| Red / Audio | Dual | | |
| Green / Position | Green | | |
| Yellow / Subtitle | Yellow | | |
| Yellow / Subtitle | Subt | | |
| Blue / L/R | Blue | | |
| REW | << | | |
| Play / Slow | Play | | |
| Stop | Stop | | |
| F.F | >> | | |
| Pause (For PVR) | Pause | | |
| Rec | Rec | | |
| | | | |
| | | | |
| | | | |

