

































































Original	Sustituto
	
Power	Power
	
Info	Info
	
TV	TV/R
	
AV	AV
	
R	Smart
	
F1	List
	
F2	Dual
	
F3	Subt
	
1	1
	
2	2
	
3	3
	
4	4
	
5	5
	
6	6
	
7	7
	
8	8
	
9	9

Original	Sustituto
	
0	0
	
Blue/Picture	Blue
	
Yellow/Sound	Yellow
	
White	Media
	
Green/Timer	Green
	
Red/Back	Red
	
P+	Ch +
	
P-	Ch -
	
Up	Up
	
Down	Down
	
Right	Right
	
Left	Left
	
OK	Ok
	
Vol+	Vol +
	
Vol-	Vol -
	
Mute	Mute
	
Pause	Pause



