



Original	Sustituto
Standby	Power
Open/Close	Eject / Surround
Prog	TV/Radio /
1	1
2	2
3	3
V-Mode	Picture / Format
4	4
5	5
6	6
A-Mode	Sound / Title
7	7
8	8
9	9
Setup	Setup / OPT /
Goto	Text / Goto
10+	Guide / EPG / -/--

Original	Sustituto
0/10	0
Title	Shift + Sound / Title
Menu	Menu / Home
Audio	Audio / Lang I/II
Subtitle	Subtitle / EQ
Angle	Info / Angle
Up	Up
Left	Left
Enter	OK
Right	Right
Down	Down
Step	Shift + Pause / Step /
Repeat	Green / APP / Repeat
A-B	Yellow / YouTube / Repeat
<<	<< / Tune-
Play	Play / Slow
Pause	Pause / Step / Freeze





Original	Sustituto	Original	Sustituto
	I<<		I<< / Preset-
	>>		>> / Tune+
	Stop		Stop / Hold
	>>		>> / Preset+
	Vol+		Vol+
	Key+		CH+ / Page+
	Virtual		Shift + Display / Media
	OSD		Display / Media
	Vol-		Vol-
	Key-		CH- / Page-
	Nothing		Shift + Setup / OPT / Tools
	Zoom		Zoom / Size
	Mute		Mute / Dimmer
	L/R/ST		Smart / List
	Tone		Exit / Cancel / Clear
	S.Effect		AV / Input / RDS

Original	Sustituto

