





















































Original	Sustituto	Original	Sustituto
	Power		Power
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	-/--		Shift + Guide / EPG / -/--
	0		0
	Recall		Back / Return
	Vol+		Vol+
	Info		Info / Angle
	EPG		Guide / EPG / -/--

Original	Sustituto	Original	Sustituto
	Prog+		CH+ / Page+
	Vol-		Vol-
	Source		AV / Input / RDS
	Prog-		CH- / Page-
	Left		Left
	Up		Up
	OK		OK
	Right		Right
	Sleep		Sleep / Timer
	Down		Down
	Menu		Menu / Home
	Fav		Fav / Marker / PC
	Format		Shift + Picture / Format
	Texte		Smart / List
	Subtitle		Subtitle / EQ
	Red/A		Red / Netflix / Search
	Green/B		Green / APP / Repeat



