



































Original	Sustituto
 Power	 Power
 Index	 Media
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Display	 Info
 Sleep	 Sleep
 CH +	 Ch +
 CH -	 Ch -

Original	Sustituto
 Q.V	 Smart
 TV / AV	 AV
 V +	 Vol +
 V -	 Vol -
 Up / CH +	 Up
 Down / CH -	 Down
 Right / V +	 Right
 Left / V -	 Left
 Menu	 Menu
 Menu	 Ok
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 I / II	 Dual
 →ISI←	 Shift + Dual
 →IPI←	 Format





Original	Sustituto	Original	Sustituto
	Zoom		Eject
	TXT		Text
	Hold		Stop
	Cancel		Back
	Subpg		Subt
	Mix		Shift + Text
	Reveal		Pre Ch

