






Original	Sustituto
 Power	 Power
 Repeat	 Green / APP / Repeat
 A-B	 Yellow / YouTube / Repeat
 Open/Close	 Eject / Surround
 N/P	 Blue / Prime Video / Random
 Subtitle	 Subtitle / EQ
 Angle	 Info / Angle
 Language	 Audio / Lang I/II
 Setup	 Setup / OPT /
 Title	 Sound / Title
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7

Original	Sustituto
 8	 8
 9	 9
 Time	 Sleep / Timer
 0	 0
 10+	 Guide / EPG / -/-
 Up	 Up
 PBC	 D.Menu / Top
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 OK
 Menu	 Menu / Home
 Vol+	 Vol+
 Vol-	 Vol-
 Zoom	 Zoom / Size
 Return	 Back / Return
 L/R	 Smart / List





Original	Sustituto
	Shift + Pause / Step /
	Shift + Play /
	TV/Radio /
	Exit / Cancel / Clear
	Mute / Dimmer
	Display / Media
	I<< / Preset-
	>>I / Preset+
	<< / Tune-
	>> / Tune+
	Picture / Format
	Stop / Hold
	Play / Slow
	Pause / Step / Freeze

Original	Sustituto

