





































Original	Sustituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Radio	 TV/R
 Time Shift	 3D
 Sleep	 Sleep
 Rec	 Rec
 Fav	 Shift + Pre Ch

Original	Sustituto
 Mouse	 Shift + Media
 www	 Media
 Back	 Back
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Vol+	 Vol +
 Vol-	 Vol -
 Smart TV	 Smart
 Home	 Shift + Smart
 Refresh	 D. Menu
 CH+	 Ch +
 CH-	 Ch -
 Red / <<	 Red
 Red / <<	 <<



