



| Original | | Sustituto | | Original | | Sustituto | |
|---|-----------|---|--------|---|----------|---|-------|
|  | Standby |  | Power |  | Recall |  | Back |
|  | Tv/Radio |  | TV/R |  | Exit |  | Exit |
|  | Mute |  | Mute |  | Up |  | Up |
|  | 1 |  | 1 |  | Down |  | Down |
|  | 2 |  | 2 |  | Right |  | Right |
|  | 3 |  | 3 |  | Left |  | Left |
|  | 4 |  | 4 |  | OK |  | Ok |
|  | 5 |  | 5 |  | CH+ |  | Ch + |
|  | 6 |  | 6 |  | CH- |  | Ch - |
|  | 7 |  | 7 |  | Vol+ |  | Vol + |
|  | 8 |  | 8 |  | Vol- |  | Vol - |
|  | 9 |  | 9 |  | EPG |  | Guide |
|  | 0 |  | 0 |  | Subtitle |  | Subt |
|  | Goto |  | Smart |  | Audio |  | Dual |
|  | Favourite |  | Pre Ch |  | TTX |  | Text |
|  | Menu |  | Menu |  | << |  | << |
|  | Info |  | Info |  | >> |  | >> |





| Original | Sustituto | Original | Sustituto |
|--|--|----------|-----------|
|  I<< |  I<< | | |
|  >>I |  >>I | | |
|  Play |  Play | | |
|  Pause |  Pause | | |
|  Stop |  Stop | | |
|  Rec |  Rec | | |
|  Repeat |  Shift + Text | | |
|  Page+ |  Shift + Ch + | | |
|  Page- |  Shift + Ch - | | |
|  PVR |  Media | | |
|  Red/USB |  Red | | |
|  Green/V-Format |  Green | | |
|  Yellow/Aspect |  Yellow | | |
|  Blue/Timer |  Blue | | |
| | | | |
| | | | |
| | | | |

| Original | Sustituto | Original | Sustituto |
|----------|-----------|----------|-----------|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

