



























































	Original	Sustituto		Original	Sustituto
	 Power	 Power		 Exit	 Exit
	 Mute	 Mute		 Up	 Up
	 1	 1		 Down	 Down
	 2	 2		 Right	 Right
	 3	 3		 Left	 Left
	 4	 4		 Ok	 Ok
	 5	 5		 Vol+	 Vol +
	 6	 6		 Vol-	 Vol -
	 7	 7		 Sound	 Shift + Dual
	 8	 8		 Pic	 Shift + Format
	 9	 9		 Ch+	 Ch +
	 0	 0		 Ch-	 Ch -
	 Audio	 Dual		 Sleep	 Sleep
	 Recall	 Back		 Aspect	 Format
	 Tv Menu	 Menu		 Freeze	 Eject
	 Source	 AV		 Tv/Radio	 TV/R
	 ChList	 List		 Text	 Text





	Original	Sustituto		Original	Sustituto
	Epg	 GUIDE			I<<
	Fav	 PRE-CH			>>I
	Info	 DISPLAY INFO			Play
	Red	 A			Pause
	Green	 B			Stop
	Yellow	 C			Rec/Rep
	Blue	 D			
	Reveal	 APP MEDIA			
	Hold	 E-MANUAL D.MENU			
	Index	 SHIFT + DISPLAY INFO	Shift +		
	Subpage	 SHIFT + TIMER AV	Shift +		
	List	 HOME SMART			
	Mix	 SETTINGS OPT			
	Subtitle	 AD SUBT			
	Size	 ECO 3D			
	<<		<<		
	>>		>>		

