



































Original	Sustituto
	Power
	Menu / Home
	Shift + 3
	Display / Media
	AV / Input / RDS
	Info / Angle
	Exit / Cancel / Clear
	Smart / List
	D.Menu / Top
	Up
	Guide / EPG / -/--
	Left
	OK
	Right
	Setup / OPT /
	Down
	Back / Return

Original	Sustituto
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Mute / Dimmer
	Text / Goto
	Subtitle / EQ
	Picture / Format
	Vol+
	CH+ / Page+
	Vol-
	CH- / Page-
	1
	2
	3
	4
	5



