





































Original	Sustituto
 Power	 Power
 Select Drive	 List
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Last View	 Pre Ch
 Radio/Tv	 TV/R
 CH/Page+	 Ch +
 CH/Page-	 Ch -
 Internet	 Smart

Original	Sustituto
 Netflix	 Media
 I<< Skip	 I<<
 Skip >>I	 >>I
 << Slow/Search	 <<
 Slow/Search >>	 >>
 Stop	 Stop
 Pause/Pause Live	 Pause
 Play	 Play
 Rec	 Rec
 i/Status	 Info
 X/Exit	 Exit
 Video Menu	 D. Menu
 Guide	 Guide
 Function Menu	 Menu
 Option	 Options
 Return	 Back
 Up	 Up





Original	Sustituto
	Down
	Right
	Left
	Ok
	Red
	Green
	Yellow
	Blue
	+ Shift + Rec
	TEXT Text
	SUBT Subt
	SLEEP Sleep
	FORMAT Format
	3D 3D
	DUAL Dual
	AV AV
	Eject

Original	Sustituto
	+ Shift + Left
	+ Shift + Right
	+ Shift + Power
	+ Shift + AV
	Vol +
	Vol -
	+ Shift + Ch +
	+ Shift + Ch -

