



Original	Sustituto	Original	Sustituto
	Power		Power
	[+]/Aspect		3D
	Input TV		TV/R
	Input AV		AV
	Menu		Menu
	[≡]/Text		Text
	[≡♦]/STTL		Subt
	APPS		Media
	i		Info
	X/Exit		Exit
	Option		Options
	Back/Return		Back
	Netflix		Shift + Smart
	Home		Smart
	Guide		Guide
	Up		Up
	Down		Down

Original	Sustituto	Original	Sustituto
	Right		Right
	Left		Left
	OK		Ok
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	CH+		Ch +
	CH-		Ch -
	1		1
	2		2
	3		3
	4		4
	5		5





	Original	Sustituto		Sustituto
	6			6
	7			7
	8			8
	9			9
	0			0
	?/Help			Dual
	Last View			Pre Ch
	<<			<<
	Play			Play
	>>			>>
	I<<			I<<
	Pause			Pause
	>>I			>>I
	Stop			Stop
	Rec			Rec
	My APP	+		Shift + Media

	Original	Sustituto

