




























| Original  | Sustituto        |
|---|------------------|
|    | Power            |
|    | Tv/Text          |
|    | 1                |
|    | 2                |
|    | 3                |
|    | 4                |
|    | 5                |
|    | 6                |
|    | 7                |
|    | 8                |
|   | 9                |
|  | 0                |
|  | AV/Input Select  |
|  | -/--             |
|  | Tracking/V-Lock+ |
|  | Tracking/V-Lock- |
|  | Vol+             |

| Original  | Sustituto     |
|---|---------------|
|    | Vol-          |
|    | Search        |
|    | Show View     |
|    | OSD/Display   |
|    | Replay        |
|    | Direct Tv Rec |
|    | I<< Index     |
|    | Index >>I     |
|    | Rec           |
|    | Pause/Step    |
|   | Menu          |
|  | OK            |
|  | Play/Up       |
|  | Stop/Down     |
|  | >>/Right      |
|  | <</Left       |
|  | SP/LP         |





| Original    | Sustituto |
|-------------|-----------|
| Timer Rec   | 3D        |
| Prog/Check  | Sleep     |
| Reset       | Back      |
| Audio       | Dual      |
| VPS/PDC     | Subt      |
| AV Link     | Media     |
| TV Aspect   | Eject     |
| Still Album | List      |
| Up          | Up        |
| Down        | Down      |
| Date+       | Right     |
| Date-       | Left      |
| On+         | Red       |
| On-         | Green     |
| Off+        | Yellow    |
| Off-        | Blue      |
| Cancel      | D. Menu   |

| Original | Sustituto |
|----------|-----------|
| Exit     | Exit      |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |
|          |           |





| Original | Sustituto |
|----------|-----------|
| Power    | Power     |
| TV/Text  | Text      |
| CH+      | Ch +      |
| CH-      | Ch -      |
| Vol+     | Vol +     |
| Vol-     | Vol -     |
| 1        | 1         |
| 2        | 2         |
| 3        | 3         |
| 4        | 4         |
| 5        | 5         |
| 6        | 6         |
| 7        | 7         |
| 8        | 8         |
| 9        | 9         |
| 0        | 0         |
| -/--     | Guide     |

| Original        | Sustituto |
|-----------------|-----------|
| AV Input Select | AV        |
| Red             | Red       |
| Green           | Green     |
| Yellow          | Yellow    |
| Blue            | Blue      |
|                 |           |
|                 |           |
|                 |           |
|                 |           |
|                 |           |
|                 |           |
|                 |           |
|                 |           |
|                 |           |
|                 |           |
|                 |           |
|                 |           |
|                 |           |
|                 |           |
|                 |           |

