































































Original	Sustituto
	 Power
	 AV / Input / RDS
	 Text / Goto
	 Audio / Lang I/II
	 Subtitle / EQ
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 Menu / Home
	 Guide / EPG / -/--
	 Up
	 << / Tune-
	 Play / Slow
	 Pause / Step / Freeze
	 >> / Tune+
	 Down

Original	Sustituto
	 Shift + Setup / OPT / Tools
	 Info / Angle
	 Vol+
	 Stop / Hold
	 CH+ / Page+
	 Vol-
	 Mute / Dimmer
	 CH- / Page-
	 1
	 2
	 3
	 Fav / Marker / PC
	 4
	 5
	 6
	 TV/Radio /
	 7





Original		Sustituto	
	8		8
	9		9
	Rotate		Display / Media
	Setup		Setup / OPT /
	0		0
	[<>]		Picture / Format
	Zoom		Zoom / Size

Original		Sustituto	

