












Original	Sustituto
 Power	 Power
 Open/Close	 Eject / Surround
 Up	 Up
 Preset/Album+	 CH+ / Page+
 I<<	 I<< / Preset-
 I<<	 Left
 Play/Pause	 Play / Slow
 Play/Pause	 Pause / Step / Freeze
 Play/Pause	 OK
 >>I	 >>I / Preset+
 >>I	 Right
 Preset/Album-	 CH- / Page-
 Down	 Down
 Mute	 Mute / Dimmer
 Disp	 Display / Media
 Stop	 Stop / Hold
 Menu	 Menu / Home

Original	Sustituto
 Max	 Smart / List
 Vol-	 Vol-
 Vol+	 Vol+
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Prog/Clock Set	 TV/Radio /
 0	 0
 Repeat/Shuffle	 Green / APP / Repeat
 Repeat/Shuffle	 Blue / Prime Video / Random
 Sleep/Timer	 Sleep / Timer







































Original		Sustituto		Original		Sustituto	
	DSC		Setup / OPT /				
	DBB		D.Menu / Top				






Original	Sustituto
 Power	 Power
 Open/Close	 Eject / Surround
 Up	 Up
 Preset/Album+	 CH+ / Page+
 I<<	 I<< / Preset-
 I<<	 Left
 Play/Pause	 Play / Slow
 Play/Pause	 Pause / Step / Freeze
 Play/Pause	 OK
 >>I	 >>I / Preset+
 >>I	 Right
 Preset/Album-	 CH- / Page-
 Down	 Down
 Disp	 Display / Media
 Mute	 Mute / Dimmer
 Stop	 Stop / Hold
 Menu	 Menu / Home

Original	Sustituto
 Max	 Smart / List
 Vol-	 Vol-
 Vol+	 Vol+
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Prog/Clock Set	 TV/Radio /
 0	 0
 Repeat/Shuffle	 Green / APP / Repeat
 Repeat/Shuffle	 Blue / Prime Video / Random
 Sleep/Timer	 Sleep / Timer










Original	Sustituto	Original	Sustituto
	DSC		Setup / OPT /
	DBB		D.Menu / Top





Original	Sustituto
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	

Original	Sustituto
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	








Original	Sustituto	Original	Sustituto
 DSC	 Setup / OPT /		
 DBB	 D.Menu / Top		






Original	Sustituto
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	

Original	Sustituto
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	





Original	Sustituto	Original	Sustituto
	DSC		Setup / OPT /
	DBB		D.Menu / Top

