

























Original	Sustituto
	Standby
	Power
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	Vol+
	Vol-
	Left
	Right
	I<< / Preset-
	>>I / Preset+

Original	Sustituto
	Stop
	Play/Pause
	Play/Pause
	I>/Resume
	Surround
	Sound
	Night
	Mute
	Repeat
	Repeat A-B
	Sleep
	DIM
	Subw +
	Rear +
	Center +
	Tv Vol+
	Subw -





[illegible]

