







































































Original	Sustituto	Original	Sustituto
	Power		Power
	Info		Info
	Search		TV/R
	Sources		AV
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	←		Pre Ch
	Home		Smart
	≡		Dual
	<<		<<
	Play		Play
	>>		>>
	Stop		Stop
	Pause		Pause
	Rec		Rec
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Netflix		Shift + Media
	Windows		Media
	Rakuten Tv		Shift + Smart
	CH+		Ch +
	CH-		Ch -
	Exit/Tv		Exit
	1		1
	2		2
	3		3





	Original	Sustituto		Original	Sustituto
	4				
	5				
	6				
	7				
	8				
	9				
	0				
	Text				
	List/Tv Guide				

