





























































Original	Sustituto	Original	Sustituto
	Power		Power
	Red/TV		Red
	Green/PC		Green
	Yellow/[≡:]/Radio		Yellow
	Blue/[]		Blue
	Input/[?]		AV
	Timer		Shift + AV
	[:≡]		Guide
	I-II/[≡I≡]		Dual
	♪ Smart		Smart
	[<>]/[+]		Format
	[] Smart		Media
	Menu		Menu
	[≡]		Text
	Up		Up
	Down		Down
	Right		Right

Original	Sustituto	Original	Sustituto
	Left		Left
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	P+		Ch +
	P-		Ch -
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	[i+]		Info





Original	Sustituto	Original	Sustituto
	P<P		Pre Ch

