







































































































Original	Sustituto	Original	Sustituto
	Power		Power
	Repeat		Text
	A-B Repeat		Options
	Shuffle		AV
	Scan		Smart
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	DVD Menu		D. Menu
	0		0
	OSD Menu		Menu

Original	Sustituto	Original	Sustituto
	Return		Back
	Up		Up
	P+		Ch +
	OK		Ok
	Left		Left
	Vol-		Vol -
	Right		Right
	Vol+		Vol +
	[...]		Subt
	Down		Down
	P-		Ch -
	Audio		Dual
	T-C		TV/R
	Angle		Format
	Zoom		Eject
	<<		<<
	I<		I<<





	Original	Sustituto		Sustituto
	Power		Power	
	1		1	
	2		2	
	3		3	
	4		4	
	5		5	
	6		6	
	7		7	
	8		8	
	9		9	
	0		0	
	Up		Up	
	OK		Ok	
	Vol -		Vol -	
	Left		Left	
	Vol +		Vol +	
	Right		Right	

	Original	Sustituto		Sustituto
	Down		Down	
	I<<		I<<	
	I<<		<<	
	>>I		>>I	
	>>I		>>	
	Stop		Stop	

