







































































Original	Sustituto
 Standby / On	 Power
 VCR Eject	 Shift + Exit
 DVD Open / Close	 Eject
 DVD / VCR	 Media
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Return	 Back
 Timer Rec	 Shift + AV
 Input Select	 AV

Original	Sustituto
 ShowView	 Smart
 Cancel	 Exit
 Title Menu / Top Menu	 Menu
 Up / CH +	 Up
 Up / CH +	 Ch +
 Down / CH -	 Down
 Down / CH -	 Ch -
 Right / TRK +	 Right
 Left / TRK -	 Left
 Enter	 Ok
 DVD Menu	 D. Menu
 Setup	 Options
 Stop	 Stop
 Play	 Play
 Pause / Still	 Pause
 I<< Skip / Index -	 I<<
 << Rew / Search	 <<





Original	Sustituto
>> F.Fwd /	>>
>>I Skip / Index	>>I
One Touch	Text
CM Skip	Format
Slow I>	Shift + >>
Rec	Rec
Rec Mode / Speed	Shift + Rec
Dubbing	3D
Audio / Audio select	Dual
Display	Info
Zoom	Shift + Eject
Repeat A-B	Shift + Text
Zero Return	Shift + Back
Counter Reset / Angle	Sleep
Subtitle / ATR	Subt
Play Mode /	Shift + Play
Clock Counter	Mute

Original	Sustituto
TV / VCR	TV/R

