







































































Original	Sustituto	Original	Sustituto
 Power	 Power	 Exit	 Exit
 Mute	 Mute	 Up	 Up
 DVD Setup	 Media	 Down	 Down
 Title	 List	 Right	 Right
 Menu (Blue)	 D. Menu	 Left	 Left
 USB/CR	 3D	 Enter	 Ok
 Nicam/A2	 Shift + Options	 1	 1
 Sleep	 Sleep	 2	 2
 Aspect	 Format	 3	 3
 Eject	 Eject	 4	 4
 Display	 Shift + Info	 5	 5
 Auto	 Back	 6	 6
 P.Mode	 Shift + Format	 7	 7
 S.Mode	 Shift + Dual	 8	 8
 DTV	 Smart	 9	 9
 Source	 AV	 0	 0
 Menu	 Menu	 +/-	 Shift + Guide





Original	Sustituto	Original	Sustituto
	EPG		Guide
	Recall		Pre Ch
	CH+		Ch +
	CH-		Ch -
	Info		Info
	FAV		Shift + Pre Ch
	Tv/Radio		TV/R
	Audio		Dual
	Vol+		Vol +
	Vol-		Vol -
	Text		Text
	Play		Play
	Pause		Pause
	Stop		Stop
	Rec/Hold		Rec
	<</Index		<<
	>>/Size		>>
	I<</Reveal		I<<
	>>I/Sbpage		>>I
	Subtitle (Green)		Subt
	Zoom		Shift + Eject
	Goto		Options
	Subtitle (Blue)		Shift + Subt
	Angle		Shift + TV/R
	Red/Program		Red
	Green/Intro		Green
	Yellow/Repeat		Yellow
	Blue/A-B		Blue

